
SECURITY SLEEVE ANCHOR ULTRA 6 LOBE (1/4" dia.)



FAST & EASY TO INSTALL IN CONCRETE, BRICK AND STONE-BASED MATERIALS



SIZE (DIA. x LENGTH) * inch	PART NUMBER Stainless Steel Head, Zinc Body	PART NUMBER Stainless Steel Head & Body			
1/4 x 1-1/4	250.1250TBSZ				
1/4 x 2	250.200TBSZ	250.200TBSS			
1/4 x 2-3/4	250.2750TBSZ	250.2750TBSS			
1/4 x 3-3/4	250.3750TBSZ**	250.3750TBSS			
1/4 x 5	250.500TBSZ				

^{*} Anchor lengths are measured from underneath the head.

Installation


- 1. Drill a hole into the base material at least 1/4" deeper than the anchor length. Make the hole the same size as the anchor diameter (1/4" hole for 1/4" anchor).
- Blow the hole clean using compressed air. Alternatively, drill the hole deep enough to accommodate embedment length and drilling dust.
- 3. Install the Ultra 6 Lobe security anchor through the fixture directly into the base material.
- 4. Tighten to required installation torque (see below).


IMPORTANT: Make sure the hole in the item being attached is slightly larger than the anchor diameter.

Allowable Tension and Shear Loads in Normal-Weight Concrete

_				CRITICAL SPACING DIST. inch	TENSION LOAD				SHEAR LOAD					
	SIZE inch	MIN. Embed. Depth			f1 > 2 000 pci /12 2 mDa\		f¹ _C ≥ 4,000 psi (27.6 mPa) CONCRETE		f¹ _C ≥ 2,000 psi (13.8 mPa) CONCRETE			INSTALL. TORQUE		
		inch			ULTIMATE lb.	STD. DEV. lb.	ALLOW lb.	ULTIMATE lb.	STD. DEV. lb.	ALLOW lb.	ULTIMATE lb.	STD. DEV. lb.	ALLOW lb.	ft. / lb.
	1/4	length + 1/4"	2-1/2	4-1/2	880	94	220	1,320	189)	330	1,440	90	360	5

¹The tabulated allowable loads are based on a safety factor of 4.0.









^{*} To determine the minimum length of anchor required, add the thickness of the material to be fastened to the minimum embedment for the diameter of anchor being installed.

^{**} Minimum quantities may apply.